

LCD SHOWERTIMER 5 MINUTES



ECOSAVERS

EcoSavers® LCD ShowerTimer 5 minutes

This digital timer unit with alarm has the ability to count down. On the back of the unit there is a suction cup that can stick to a smooth surface. It helps children and adults alike to save water and energy.

When display shows 0m00s press START button. The timer will reset to 5 minutes and will start counting down.

Press START button to pause and press START button again to resume the countdown.

When the timer reaches 0m00s, the alarm will sound for 1 minute or can manually be stopped by pushing the START button.



BATTERY INFORMATION:
Battery type: AG10



ECOSAVERS®