

LETTERBOX BRUSH




ECOSAVERS

EcoSavers® Letterbox brush

The Letterbox Brush from EcoSavers helps you to eliminate draughts coming from the letterbox opening in your door. For example the gap left open when newspapers are not pushed through completely.

Just attach the letterbox brush behind the inside opening in the door with 4 screws and you can eliminate draughts coming into your house. Saves energy and money right away. Simple and easy!



ECOSAVERS®