

# OUTDOOR EASY TIMESWITCH



**ECOSAVERS**

# EcoSavers® Outdoor Easy Time Switch

The EcoSavers Outdoor Easy Time Switch is specially designed for use in combination with outdoor lighting. Because dusk-dawn times changes through the season, you can easily adjust the duration settings by turning the time selection wheel to the required operating duration after dusk.

## Product features

- IP44 AC socket port
- Selection wheel
- Indication LED
- Daylight sensor



## Technical details

Voltage:	230V / 50Hz
Maximum load:	16A / 3.680W
Power consumption:	0.7W
Size:	113 x 87 x 58 mm
Waterproof rating:	IP44



**ECOSAVERS®**