

# SHOWERTIMER DROP



**ECOSAVERS**

# EcoSavers® LCD Showertimer Drop

The shower Timers from EcoSavers® are innovated new products to educate children and adults to learn about saving water and energy.

Easy set the minutes and seconds you want to shower and after the time set the timer will beep as a sign to stop showering. To limit the time you shower you can save lots of water and energy, every day again.

This product with digital count-down timer with alarm can easily be mounted on the shower wall by the integrated suction cup.

Start saving water and energy today with the EcoSavers® Shower Timers!



## SPECIFICATIONS

Time	1 sec. – 99 min / 59 sec.
Buttons	1. minute 2. seconds 3. Start/stop
Reset	push minute and second button together
Battery Type	LR44 (AG 13) included

## SIZES

Drop Shape	75 x 60 x 20 mm (included suction cup)
------------	--



**ECOSAVERS®**